

Safety Data Sheet

R-290 PROPANE

1. CHEMICAL PRODUCT AND COMPANY IDENTIFICATION

PRODUCT NAME: PROPANE
OTHER NAME: Liquefied Petroleum Gas (LPG)
USE: Refrigerant Gas
DISTRIBUTOR: Shandong Vcher Electrical Appliance Co., Ltd.
Add: Hutouya Industrial Zone, Laizhou, Shandong, China

FOR MORE INFORMATION CALL:
(Monday-Friday, 8:00am-5:00pm)
+86 535 2882018

2. HAZARDS IDENTIFICATION

CLASSIFICATION: Flammable Gas, Gas under pressure, Compressed Gas
SIGNAL WORD: DANGER
HAZARD STATEMENT(S): Extremely flammable gas, Contains gas under pressure, may explode if heated
SYMBOL(S): Flames, Gas Cylinder



PRECAUTIONARY STATEMENT(S):

Prevention: Keep away from heat, sparks, open flame, and hot surfaces. No Smoking
Response: Leaking gas fire: Do not extinguish unless leak can be stopped immediately. Eliminate all ignition sources if safe to do so.
Storage: Protect from sunlight, store in a well ventilated place.

EMERGENCY OVERVIEW:

Flammable gas. Liquid under high pressure.

POTENTIAL HEALTH EFFECTS:

Effects of Overexposure:

Eye Contact

No known significant effects or critical hazards.

Skin Contact

No known significant effects or critical hazards.

Inhalation

Acts as simple asphyxiant.

Ingestion

Ingestion is not a normal route of exposure for gases

3. COMPOSITION / INFORMATION ON INGREDIENTS

<u>INGREDIENT NAME</u>	<u>CAS NUMBER</u>	<u>WEIGHT %</u>
Propane	74-98-6	100

COMMON NAMES and SYNONYMS

Liquefied Petroleum Gas (LPG) R-290

There are no impurities or stabilizers that contribute to the classification of the material identified in Section 2

4. FIRST AID MEASURES

SKIN:

In case of contact, immediately flush skin with plenty of water. Remove contaminated clothing and shoes. Wash clothing before reuse. Thoroughly clean shoes before reuse. Get medical attention.

EYES:

Immediately flush eyes with plenty of warm water for at least 15 minutes. Get medical attention.

INHALATION:

Immediately remove to fresh air. If breathing has stopped, give artificial respiration. If breathing is difficult, qualified personnel may give oxygen. Get medical attention immediately.

INGESTION:

Do NOT induce vomiting unless directed to do so by medical personnel. Never give anything by mouth to an unconscious person. Get medical attention if symptoms appear.

ADVICE TO PHYSICIAN:

No specific treatment. Contact poison treatment specialist immediately if large amounts have been inhaled or ingested.

5. FIRE FIGHTING MEASURES

FLAMMABLE PROPERTIES

FLASH POINT:

AUTO IGNITION TEMPERATURE:

468 C (874 F)

UPPER EXPLOSIVE LIMIT (volume % in air):

9.5%

LOWER EXPLOSIVE LIMIT (volume % in air):

2.2%

EXTINGUISHING MEDIA:

These products are carbon oxides (CO,CO₂).

UNUSUAL FIRE HAZARDS:

Extremely flammable in presence of open flames, sparks and static discharge of oxidizing materials.

FIRE FIGHTING INSTRUCTIONS:

CO₂, dry chemicals, water spray, or fog. If involved in fire, shut off flow immediately if it can be done without risk. Apply water from a safe distance to cool container and protect surrounding area. Extremely flammable. Gas may accumulate in confined areas, travel considerable distance to source of ignition and flash back causing fire or explosion. Fire fighters should wear appropriate protective equipment and self-contained breathing apparatus (SCBA) with a full face piece operated in positive pressure mode.

6. ACCIDENTAL RELEASE MEASURES

SPILL AND LEAK PROCEDURES:

Immediately contact emergency personnel. Keep unnecessary personnel away. Use suitable protective equipment (Section 8). Shut off gas supply if this can be done safely. Isolate area until gas has dispersed. Avoid dispersal of spilled material and runoff and contact with soil, waterways, drains and sewers.

7. HANDLING AND STORAGE

NORMAL HANDLING:

Keep container closed. Use only with adequate ventilation. Keep away from heat, sparks and flame. To avoid fire, minimize ignition sources. Use explosion-proof electrical (ventilating, lighting and material handling) equipment. Do not puncture or incinerate container. High pressure gas. Use equipment rated for cylinder pressure. Close valve after each use and when empty. Protect cylinders from physical damage; do not drag, roll, slide, or drop. Use a suitable hand truck for cylinder movement.

STORAGE RECOMMENDATIONS:

Keep container tightly closed. Keep container in a cool, well-ventilated area. Cylinders should be stored upright, with valve protection cap in place, and firmly secured to prevent falling or being knocked over. Cylinder temperatures should not exceed 52°C (125°F).

8. EXPOSURE CONTROLS / PERSONAL PROTECTION

ENGINEERING CONTROLS:

Use only with adequate ventilation. Use process enclosures, local exhaust ventilation, or other engineering controls to keep airborne levels below recommended exposure limits. The engineering controls also need to keep gas, vapor or dust concentrations below any explosive limits. Use explosion-proof ventilation equipment

PERSONAL PROTECTION:

SKIN PROTECTION:

Personal protective equipment for the body should be selected based on the task being performed and the risks involved and should be approved by a specialist before handling this product.

EYE PROTECTION:

Safety eyewear complying with an approved standard should be used when a risk assessment indicates this is necessary to avoid exposure to liquid splashes, mists or dusts.

RESPIRATORY PROTECTION:

Use a properly fitted, air-purifying or air-fed respirator complying with an approved standard if a risk assessment indicates this is necessary. Respirator selection must be based on known or anticipated exposure levels, the hazards of the product and the safe working limits of the selected respirator.

The applicable standards are (US) 29 CFR 1910.134 and (Canada) Z94.4-93

EXPOSURE GUIDELINES

(Exposure Limits)

INGREDIENT NAME

Propane

ACGIH TLV

1000 ppm

OSHA PEL

1000 ppm

OTHER LIMIT

9. PHYSICAL AND CHEMICAL PROPERTIES

APPEARANCE:	Colorless, liquefied compressed gas
PHYSICAL STATE:	Gas at ambient temperature
ODOR:	Odorless
SOLUBILITY IN WATER:	0.0244 g/liter
BOILING POINT:	-43.2°F (-41.79°C)
VAPOR PRESSURE :	109 psig
FLASHPOINT:	-104°C (-155°F)
EVAPORATION RATE:	Not available
FLAMMABILITY:	Extremely flammable in the presence of ignition sources or oxidizing materials
LEL/UEL:	2.2% / 9.5%
PARTITION COEFFICIENT	
n-OCTANOL/WATER:	Log Pow: 1.09
AUTO IGNITION TEMPERATURE:	468 C (874 F)
DECOMPOSITION TEMPERATURE:	Data not available
VISCOSITY:	Not applicable
VAPOR DENSITY:	1.6 (Air=1)
% VOLATILES BY VOLUME:	100%
DENSITY:	0.116 lb / cu ft
pH:	Not applicable
MELTING/FREEZING POINT:	-302.6°F (-185.89°C)
SPECIFIC VOLUME (ft³/lb):	8.62069
MOLECULAR FORMULA:	C ₃ H ₈
MOLECULAR WEIGHT:	44.11 g/mole
BOILING/CONDENSATION POINT :	-161°C / 259°F

10. STABILITY AND REACTIVITY

CHEMICAL STABILITY

The product is stable.

REACTIVITY:

Not reactive under normal storage conditions.

INCOMPATIBILITY WITH OTHER MATERIALS:

Extremely reactive or incompatible with oxidizing agents.

CONDITONS TO AVOID:

Avoid all possible sources of ignition (spark or flame). Do not cut, weld, braze, solder, drill, or grind container

11. TOXICOLOGICAL INFORMATION

TOXICITY DATA:

IDLH: 2100 ppm

Chronic effects on humans: Causes damage to the following organs: the nervous system.

Acute toxic effects on humans: No specific information is available in our database regarding the other toxic effects of this material for humans.

SPECIFIC EFFECTS:

Carcinogenic effects: No known significant effects or critical hazards.

Mutagenic effects: No known significant effects or critical hazards.

Reproductive toxicity: No known significant effects or critical hazards.

12. ECOLOGICAL INFORMATION

DEGRADABILITY (BOD):

Products of degradation: These products are carbon oxides (CO,CO₂) and water.

Toxicity of the products of biodegradation: The product itself and its products of degradation are not toxic.

Environmental fate: Not available

Environmental hazards: No known significant effects or critical hazards.

Toxicity to the environment: Not available.

13. DISPOSAL CONSIDERATIONS

Product removed from the cylinder must be disposed of in accordance with appropriate Federal, State, and local regulations.

14. TRANSPORT INFORMATION

US DOT ID NUMBER: UN 1978

US DOT SHIPPING NAME: PROPANE

US DOT HAZARD CLASS: 2.1

US DOT PACKING GROUP: NA

15. REGULATORY INFORMATION

U.S. FEDERAL REGULATIONS:

TSCA 8(b) inventory: Propane

SARA 302/304/311/312 extremely hazardous substances: No products were found.

SARA 302/304 emergency planning and notification: No products were found.

SARA 302/304/311/312 hazardous chemicals: Propane

SARA 311/312 MSDS distribution – chemical inventory – hazard identification: Propane: Fire hazard, Sudden Release of Pressure

Clean Water Act (CWA) 307: No products were found.

Clean Water Act (CWA) 311: No products were found.

Clean Air Act (CAA) 112 accidental release prevention: Propane

Clean Air Act (CAA) 112 regulated flammable substances: Propane

Clean Air Act (CAA) 112 regulated toxic substances: No products were found.

STATE REGULATIONS:

Pennsylvania RTK: Propane: (generic environmental hazard)
Massachusetts RTK: Propane
New Jersey: Propane

CALIFORNIA PROPOSITION 65: The ingredients in this product do not contain any chemicals known to State of California to cause cancer, birth defects, or any other reproductive harm.

CANADA

WHMIS (Canada): Class A: Compressed gas
Class B-1: Flammable gas
CEPA DSL: Propane

16. OTHER INFORMATION

HAZARD RATING SYSTEMS:

NFPA RATINGS:

HEALTH =1
FLAMMABILITY =4
INSTABILITY =0
SPECIAL =None

HMIS RATINGS:

HEALTH =1
FIRE HAZARD =4
REACTIVITY =0
PERSONAL PROTECTION =C

DISCLAIMER

Shandong Vcher Electrical Appliance Co., LTD believes that the information and recommendations contained herein (including data and statements) are accurate as of the date hereof). NO WARRANTY OF FITNESS OR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY, OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be valid where such product is used in combination with any other methods of use of the product and of the information referred to herein are beyond the control of National Refrigerants. National Refrigerants expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information.